



190.2

Hubarmstellung 15° / Boom position 15° /
Faites tonner la position à 15° / Lance posición 15°

† - Traglast/Lifting capacity/En soulèvement la capacité /
Levantando capacidad/ in "t"

m - Masse/Measurement/Des mesure/De medición in "m"

- Optional
 - Manuelle Verlängerung
Manual extension
L'extension manuelle
Extensión manual
 - Zusätzlicher Lasthakenpunkt am Nockenarm
Additional load hook point at jib
Supplémentaires point crochet à flèche
Carga adicional punto de gancho en la horca

190.2

